



A PerTronix Performance Brand ~ [www.pertronixbrands.com](http://www.pertronixbrands.com) ~ 909 599-5955

### ***Installation Instructions & Warranty Information***

D660YA, D660YS ~ 1960-65 Ford Falcon, Ranchero,  
Mercury Comet, 260-302 V8  
Long Tube Tri Y Headers



**2**

This product is legal for use on 1975 and older Non-Catalyst equipped vehicles and is considered a "Replacement Part" per California Air Resources Board regulations, providing ALL emissions sensitive components are retained, including EGR, A.I.R., Heat Risers, etc. and any original or retrofit PCV or NOx device is required for the year of the vehicle. Failure to retain any of these components, or use on ANY originally catalyst equipped vehicles, would render this product illegal for street or off highway use and may only be used for Closed Course Competition.



#### **WARNING:**

This product can expose you to chemicals including Lead, Nickel, Cadmium and Chromium which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

## ***PLEASE READ BEFORE PROCEEDING***

PerTronix® thanks you for choosing a Doug's Headers Product. To realize the potential of Doug's Headers engineering and excellent fit, Please Read and Understand these instructions completely prior to starting the installation.

Check that you received all the parts listed on the parts list, if you have any concerns, please contact PerTronix before continuing. Headers will have the part number stamped in the flange.

Many factors affect the installation of exhaust headers, including worn or aftermarket motor mounts, previous accident damage, aftermarket cylinder heads that may have relocated port or spark plug locations, suspension and steering changes, sagging of original unibody structures due to age.

Coating Notes: Coatings can be marred during installation if you are not careful. If you are breaking in a new motor, the extreme heat can alter the appearance of the coating and this is not a warranty issue. We recommend breaking in new motors with stock manifolds or an old set of headers.

We use sealing beads on all our headers. The raised bead creates a better seal virtually eliminating leaks if installed properly. It is important to install all header bolts lightly snug and then tighten to factory torque specs starting in the center and working outward.

Before starting, allow the vehicle to cool, disconnect the battery, and spray a penetrating oil on all hardware and fittings that will need to be removed. Once you remove your manifold, clean the sealing surface on the head of any old gasket debris or carbon build up.

Work Smart – Work Safe! Most Header and Exhaust Installation are best performed on a lift. If a lift is not available, raise the vehicle and support on quality Jack Stands on level ground. Do not rely on a jack!

### **DISASSEMBLY**

1. Remove the exhaust pipes from the stock manifolds.
2. Remove the spark plug wires and spark plugs. Remove the starter.
3. Remove the stock manifolds.
4. Clean the cylinder heads of any remaining gasket material and carbon build up.
5. Remove the Clutch Z Bar on standard trans cars.
6. Unbolt the Power Steering Ram on PS equipped cars and bracket from the frame rail.

### **INSTALLATION**

1. Place a board between the oil pan and a jack. Remove the driver side motor mount bolt and jack the driver's side of the motor up about 2".
2. From below, work the header up into position. Install 2 header bolts loosely to hold the header, then lower the motor back into position and replace the motor mount bolt.

3. With the gasket in place, install the header bolts and washers. Tighten evenly starting in the center and working out.
4. Place a board between the oil pan and a jack. Remove the passenger side motor mount bolt and jack the passenger side of the motor up about 2".
5. From below, work the header up into position. Install 2 header bolts loosely to held the header, then lower the motor back into position and replace the motor mount bolt.
6. Replace the starter.
7. With the gasket in place, install the header bolts and washers. Tighten evenly Starting in the center and working out.
8. Replace the clutch Z-Bar.
9. On Power steering cars, install the Doug's power steering ram drop down bracket #H7609 and install the power steering ram. Check routing of power steering hoses so they do not contact the header under full left and right turn. Adjust as necessary.
10. Replace the spark plugs and wires and connect the negative battery cable.

### **IMPORTANT CHECK LIST**

- Be sure that all brake lines, transmission lines, and fuel lines are clear of headers and/or connector pipes.
- All spark plug wires, battery cables, or other electrical components should be clear of headers and/or connector pipes.
- If dipstick tube was removed, make sure it is installed properly and that the dipstick has been replaced.
- Double-check the tightness of all bolts including brackets and accessories.

### **START THE ENGINE**

Start the engine and allow it to warm up to operating temperature. Check for any unusual noises or exhaust leaks. If everything is OK, stop the engine and tighten all bolts while the engine is still warm. **NOTE:** Check the bolts periodically to make sure they have not loosened. Re-tighten after the first 500 miles and then again at 1000 miles

#### **PARTS LIST:**

1 Left side header	1 Right side header
2 Header Gaskets	2 Collector Gaskets
2 Reducers	16 3/8 x 1" Header Bolts
22 Lockwashers	6 3/8-16 x 1 1/4" Hex head bolts
6 3/8-16 Hex Nut	

#### **DOUG'S HEADERS LIMITED WARRANTY**

All Doug's Headers and Exhaust products are guaranteed, to the original purchaser, to be free of defects in material and workmanship for one year from date of purchase. This warranty covers the replacement or repair of the product and does not cover the cost of removal and installation, customer applied coatings, or Any discoloration or corrosion of finished surfaces.

Damage or product failure resulting from collision, improper installation, off road use, road hazards, the use of exhaust insulating wrap, or rust occurring after installation is not covered by the warranty. This warranty extends only to the original purchaser.

Should a part be deemed defective, it should be returned to the original selling retailer and must be accompanied by the sales receipt. If there is no retailer in your area, contact PerTronix direct for a return authorization and return the part prepaid to the factory for inspection. PerTronix reserves the right to replace or repair the alleged defective part and return the part freight collect.