

Questions?

Reach us by phone or email. 713.305.7881 james@longmadeco.com

Quick Notes:

Our fixtures are for dry and indoor locations only. Use LED bulbs with an 11 watt max in our fixtures. To avoid fingerprints use clean gloves when installing.

Installation

CAUTION: RISK OF ELECTRIC SHOCK. TURN OFF POWER AT BREAKER BEFORE INSTALLING. LONG MADE CO, LLC. RECOMMENDS THAT THIS PRODUCT AND ALL OUR HARDWIRE FIXTURES BE **INSTALLED BY A QUALIFIED ELECTRICIAN ONLY**.

- 1. Turn off power at breaker.
- 2. Attach provided universal hardwire bracket to junction box using the screws that came with your junction box. These screw are not provided by us. Ensure your junction box is suitable for the weight and size of this fixture.
- 3. Connect the ground wire from the junction box to the hardwire bracket and fixture, then connect the other two wires from the fixture to the two corresponding wires from the junction box. Utilize appropriate wire nuts for all wire connections and be sure to follow the manufacturer's directions when installing them.
- 4. Be careful not to pinch wires or damage wire insulation when adjusting wires back into the junction box hole.
- 5. Align the fixture canopy/wall plate over corresponding holes in the hardwire bracket and attach with the provided screws. Do not over tighten screws or this will deform the fixture's plate.

