

SAFE ZONE

ALIGN WITH TOP EDGE OF 2X4



PLACE DRILL TEMPLATE ON 2X4

HAMMER SMALL DIVOT
WITH NAIL ON BOTH CENTERS
WITHOUT MOVING TEMPLATE

REMOVE DRILL TEMPLATE
DRILL BOTH DIVOTS THRU
WITH 25/64 DRILL

FOR MORE ACCURACY DRILL
WITH 3/16" DRILL FIRST



A
L
I
G
N
W
I
T
H
E
D
G
E
O
F
2
X
4

A
L
I
G
N
W
I
T
H
E
D
G
E
O
F
2
X
4

SAFE ZONE



QUESTIONS? (888)356-6051 M-SAT 10-6 ET

ASSEMBLY INSTRUCTIONS

CUT 4 LEGTHS OF 2X4 TO DESIRED LEG LENGTH
CUT 1 CENTER SECTION TO DESIRED LENGTH
USE DRILL TEMPLATE ON REVERSE SIDE ON ALL 4 LEGS
(ONE END ONLY)

BOLT BRACKETS TO 2X4'S WITH SUPPLIED HARDWARE
INSERT CENTER SECTION INTO TOP SOCKETS
PULL 2X4 LEGS OUTWARDS FOR STABILITY

LOOSEN TOP WINGNUT AND REMOVE CARRIAGE BOLT
TO FOLD LEGS FOR EASY STOWAGE | TRANSPORT