

Manual Center Stand installation manual for Harley Touring models 1998 to 2008

****Note this Center stand will only work on motorcycles with
rear air suspension and stock size wheel and tire****

1.) Remove zip tie located here on the right side rear frame on your stock Harley.



2.) Locate The lock Crossbar



3.) Slide in the lock cross bar as shown in the pictures below until the washers and nut holes line up with the holes on the bottom frame cross bar



4.) Slide the center Stand underneath the frame crossbar with the foot push down lever on the left side of the bike (kickstand side) and simply line up the 2 holes on the center stand with the 2 holes on the frame crossbar and lock crossbar once all the holes are lined up use the 2 provided bolts and lock washers with a 3/4" socket to bolt down the center stand to the bike.





5.) Installation is now Complete. Now sit on your bike and Air up your rear shocks the center stand will automatically retract to the riding position.

6.) When you get to your destination using your left heel lower the center stand by pushing down on the center stand lever once the lever is down, keep your foot on the lever and release the air in your Shocks completely this will allow the weight of the bike to transfer over to the center stand therefore keeping your bike up straight. You may now get off your bike and enjoy the look and stability of your new center stand.

****Make sure and always use center stand on level surfaces (concrete, asphalt , tiles , pavers etc.) Do Not use the center stand in uneven and/or soft surfaces like (grass, sand, etc.)****

