

**HARLEY AIR RIDE SUSPENSION KIT**



To Solenoid  
T Fitting

For Compressor

Attach  
Shock  
Fittings  
to  
Airline

**Compressor**



**T Fitting**

To Left  
Shock



To Right Shock

To Solenoid  
T Fitting



**Shock  
Bolts**

To Relay  
Harness

To Pos Battery

Compressor  
Clamp

Momentary  
Up/Down Switch

To Solenoid



**1/4"  
Airline**

To Compressor

To Neg Battery

**Shocks**

**Relay  
Harness**

To Relay  
Harness

**Solenoid**

To Shock  
T Fitting

To Compressor

