

COVER FOR 18" WIDE PLUNGE BENCH/TRAYS E11(01)



Assembly Instructions

COMPONENTS

Code	Components		Length of cover					
			20"	40"	60"	80"	100"	Extra 20"
A	End Connecting rail	T' 18"	2	2	2	2	2	--
B	Side Connecting Rail	T' 20"	2	4	6	8	10	2
C	Front Left Corner Upright	L' 14"	1	1	1	1	1	--
D	Front Right Corner Upright	L' 14"	1	1	1	1	1	--
E	Front Centre Upright	T' 14"	--	1	2	3	4	1
F	Back Left Corner Upright	L' 16 3/4"	1	1	1	1	1	--
G	Back Right Corner Upright	L' 16 3/4"	1	1	1	1	1	--
H	Back centre Upright	T' 16 3/4"	--	1	2	3	4	1
I	Top left End Rail	L' 18 1/8"	1	1	1	1	1	--
J	Top Right End Rail	L' 18 1/8"	1	1	1	1	1	--
K	Top Centre Rail	T' 18 1/8"	--	1	2	3	4	1
L	Plastic End Panels		2	2	2	2	2	--
M	Plastic Sheet – Front	20" x 13"	1	2	3	4	5	1
N	Plastic Sheet – Top Front	20" x 9"	1	2	3	4	5	1
O	Plastic Sheet – top Back	20" x 9"	1	2	3	4	5	1
P	Plastic Sheet – Back	20" x 16"	1	2	3	4	5	1
Q	Cover Bar	20"	1	2	3	4	5	1
R	Hinge	20"	2	4	6	8	10	2
S	Catch Bar	20"	1	2	3	4	5	1
T	Knob		1	2	3	4	5	1
U	Edging Strip		1	2	3	4	5	1
	Bolts (short/long)		37/2	68/4	99/6	130/8	161/10	31/2
	Nuts		40	74	108	142	176	34

1. Please identify and check the components.
2. Attach the side and end connecting rails to the top of the bench/tray using the existing bolts
3. Bolt the corner uprights and plastic end panels to the inside of the connecting rails and then the centre uprights, incorporating the catch bar at the front (see diag.3).
4. Bolt on the top rails.
5. Assemble the plastic cover sections as illustrated. Position each section of cover over the supporting framework and bolt in position (back and top back panels).

