



Place the log sections together as shown. Secure these in place using 2x50mm screws Position these in the top and the bottom logs.

Make sure that you are screwing into the ends of the other section.

