

## **OVERHEAD SPRAY KIT** J2 (21)

### **Installation Instructions**

#### **COMPONENTS**

<b>Components</b>	<b>8' x 10'</b>	<b>10' x 10'</b>
Tube 61cm (24") with fittings	1	1
Tube 120cm (48") with fittings	1	1
Brass Pipe & Hose fitting	1	1
Nozzles & Adaptors	2	2
Fixing Supports & Bolts	3	4
Hooks	3	4

1. Fasten the brackets in the roof glazing bars, as near the ridge as possible, and equally spaced. Clip on the suspension hooks.
2. Rest the pipe work onto the hooks. The pipe should be as level as possible so adjust the hooks and fittings if necessary.
3. Screw the black adaptors into the holes in the pipe work being careful not to over tighten.
4. Push the blue coloured spray heads firmly into the adaptors.
5. Connect a hose from your mains water supply to the brass coupling connector.

#### **N.B.:**

This system is also ideal for use outdoors in vegetable or soft fruit areas.

