## Gardeners Cloche P8 (09)

## Assembly instructions

## Components

Ridge Plate (aluminium sheet)	x 1
Side Panels (polypropylene)	x 2
End Panels (polypropylene)	x 2
Lower End Wire	x 2
Upper End Wire	x 2
Handle Straps	x 2
Ground Pegs	x 4
Nuts & Bolts	x 12

1. Please check all components.

2.

Bolt the two side panels onto the underside of the ridge plate as shown. The two handle straps also need to be attached at this point.

