

SELF WATERING TRAY Q3(01)
Assembly Instructions



COMPONENTS:

| Size | Plastic Reservoir Tray | Aluminium Insert | Capillary Matting | Wick |
|-------------|------------------------|------------------|-------------------|------|
| 16 x 12½" | 1 | 1 | 1 | 1 |
| 29¾" x 7" | 1 | 1 | 1 | 1 |
| 24" x 24" | 1 | 2 | 1 | 1 |
| 39½" x 16" | 1 | 1 | 1 | 1 |
| 47¼" x 21¾" | 1 | 2 | 1 | 1 |
| 31" X 15" | 1 | 1 | 1 | 1 |

1. Please check the components.
2. Place the aluminium insert(s) in the plastic tray with the flat surface to the top. Put the capillary matting on top of the insert – place the wick one end under the matting on the insert and trail the other in the plastic tray.
3. Fill the plastic tray with water to just below the top of the insert. Place your pots or seed trays on top of the capillary matting.
4. As plants take up water from the matting, the matting will take water from the plastic reservoir tray. (So from time to time top up the plastic tray with water).

