




HEAVY DUTY FRUIT CAGE T10(14)
MODEL: 7ft high x 16ft wide
Assembly Instructions



Components	Length						
	16'	24'	32'	40'	48'	56'	64'
A 95" Horizontal Tube	12	17	22	27	32	37	42
B 95" Vertical Tube	9	12	15	18	21	24	27
C1 Corner Joint 	4	4	4	4	4	4	4
C2 Side Joint 	4	6	8	10	12	14	16
C3 Internal Joint 	1	2	3	4	5	6	7
D Tube Caps	9	12	15	18	21	24	27
Netting	30	40	50	60	70	80	90
Netting Ties	50	100	100	150	150	200	200
Netting Pegs	20	25	30	35	40	45	50

1. Please check the components.
2. Insert a tube cap into one end of each vertical tube.
3. Using a 1/4" Allen Key, attach a connecting joint to the capped end of each vertical tube. The tube goes to the top of the inside of the joint.
4. If waist rails are being fitted, the connectors need to be slid on to the uprights at this point.
5. Mark out the ground where each vertical is to be placed and push in to a depth of approximately 12".
6. Connect the uprights using the 95" Horizontals and waist rails, if being fitted, ensuring that the Alan nuts are tight.
7. Once the whole framework is assembled the netting can be attached.
 Start at a corner vertical and go right around the sides, back to where you began, wrapping the netting around the horizontal tube work and attaching it to itself using the netting ties as you go.
 Use separate piece for the roof and secure to the side net using the ties.

* To prevent snow damage during the winter, remove the roof netting or replace with pigeon netting.

