




HEAVY DUTY FRUIT CAGE T11(07)
MODEL: 7ft high x 24ft wide
Assembly Instructions



Components			Length						
			24'	32'	40'	48'	56'	64'	72'
A	Horizontal Tube	95"	24	31	38	45	52	59	66
B	Vertical Tube	95"	16	20	24	28	32	36	40
C1	Corner Joint		4	4	4	4	4	4	4
C2	Side Joint		8	10	12	14	16	18	20
C3	Internal Joint		4	6	8	10	12	14	16
D	Tube Caps		16	20	24	28	32	36	40
	Netting		52	65	78	91	104	117	130
	Netting Ties		100	150	150	200	200	250	250
	Netting Pegs		30	35	40	45	55	60	65

1. Please check the components.
2. Insert a tube cap into one end of each vertical tube.
3. Using a 1/4" Allen Key, attach a connecting joint to the capped end of each vertical tube. The tube goes to the top of the inside of the joint.
4. If waist rails are being fitted, the connectors need to be slid on to the uprights at this point.
5. Mark out the ground where each vertical is to be placed and push in to a depth of approximately 12".
6. Connect the uprights using the 95" Horizontals and waist rail tubes if being fitted ensuring that the Alan nuts are tighten the whole framework is assembled the netting can be attached.
 Start at a corner vertical and go right around the sides, back to where you began, wrapping the netting around the horizontal tube work and attaching it to itself using the netting ties as you go.
 Use separate piece for the roof and secure to the side net using the ties.

* To prevent snow damage during the winter, remove the roof netting or replace with Pigeon Netting.

