

**CROP SUPPORT FRAME** T13 (06)  
**Assembly Instructions**



**COMPONENTS:**

Components	Length	
	8' Pack	Ext Pack
Hoop	3	1
48" Horizontal	4	2
21 1/2" Horizontal	3	1
36" Vertical	6	2
4 Way Joint	4	-
5 Way Joint	2	2
Spike	6	2

1. Please check the components.
2. Assemble the framework as shown in the diagram using a rubber or wooden mallet to knock the tubes onto the joints, until the tube is up against the shoulder of the joint.



3. Push the verticals into the ground to a depth of approx. 1ft (12")