


6' Waist Rails T19

For Standard and Deluxe Fruit Cage



Components

A. Horizontal Tubes	69 ¼" (175cm)	x 1	(30 ¾" (78cm) if being fitted in a door section)
B. Vertical Tubes	4" (10cm)	x 2	
C. Double Clip & Screws		x 2	
D. Corner Joint		x 2	
E. End Spike		x 2	

1. Assemble the Waist Rail as shown below.
2. Slide the Double Clips onto the existing frame uprights and secure at the desired height using the self tapping screws, making sure the vacant hole is inner most.
3. Tighten the screws until they bight into the tube wall.
4. Insert each end of the Waist Rail into the Double Clip and again secure using the self tapping screws until they bight into the tube.
5. If there are adjacent Rails, secure the Double Clips one above the other then set the rail so that the top edges are level.

