SETUP INSTRUCTIONS



STYLE 1-1 (STRAIGHT PANEL BACKDROPS)



Backdrop size: 10'wide x 8'H

Step 1	Backdrop Width 10'	Base plates placement Place the base plates in the desired location at the width of the backdrop. You can use 10' crossbar to measure the width from pin to pin. *If you are making the backdrop on hardwood, laminate or other floor which may get damaged, we suggest using a plate size cardboard underneath the plates.
Step 2		Erecting uprights Check the base plate pin, it should not be wobbly. If needed, turn the pin in the clockwise direction to tighten. Now slide the upright lower section on to the pin.
Step 3		Adding drape panels Set the crossbar to 10' width. (check our hardware instructions if you need help in operating crossbar) Slide 4 to 7 (depending on the type) drape panels through their 4" pocket on to the crossbar as per your chosen design sequence. In this example, we are using 7 lycra drape panels of 2 different colors.

NOV 18, 2019

SETUP INSTRUCTIONS



STYLE 1-1 (STRAIGHT PANEL BACKDROPS)

Step 4



Hanging crossbar

Hang the crossbar on the uprights.

*It is recommended to take help of another person here to hold the other end of the crossbar.

Step 5



Distributing drape panels

Distribute drape panels on the crossbar as per your chosen design. Here we distributed all panels evenly on 10' crossbar.

*Slide the drape on to the upright at both ends of the crossbar to cover the uprights. You may also use pole sleeves to cover uprights.

Step 6



Raising the backdrop

Raise the backdrop to the desired height by raising the upright in small sections.

*Do not raise more than 18" at once.

(check our hardware instructions if you need help in operating upright)

Step 7



Aligning the drapes

Align each drape panel straight and cover the gaps between the drape panels. Extra drape length at the bottom can be folded to the back.

Add any accessories and hanging décor you may need.

Enjoy your backdrop

NOV 18, 2019 2