



## Assembling your Concrete Dining Table

Concrete Tabletop with a Concrete Table Base

### PRIOR TO ASSEMBLING YOUR TABLE

- Ensure you have a lifting and assembly plan in place before lifting your tabletop and base
- Please ensure you have sufficient hands and help available before trying to lift the item/s. It is best to have an additional non-lifting helper whose role will be to guide you on placement.
- Whilst the tabletop and base is concrete, it can be damaged if not handled with care. While lifting and handling the item/s, please do so with great care.

### EQUIPMENT

- Concrete Tabletop
- Concrete Table Base
- Sikaflex polyurethane glue OR Silicon
- Level
- Packers
- Measuring Tape
- Clean cloth

### ASSEMBLY PROCEDURE

1. Ensure you have a clean and spacious area to work in, your table will need to be assembled on a flat and stable surface.
2. On the underside of your tabletop, you will see we have drawn the location of your table base/s.
3. If you have two separate legs/bases, grab your measuring tape, measure the distance between the bases, and place the concrete bases in the desired location to line up with the markings on the underside of your tabletop. If it is a single concrete base, place your base in the desired location.
4. If you have purchased a smooth concrete base, you may notice a seam line in your base, make sure this seam line is facing a less visible direction, so it is less visible to you.
5. Make sure the base/s is level and stable before lifting your tabletop. Adjust the base if necessary, using packers.
6. Wipe over your table base so it has a clean surface for the Sikaflex glue or Silicon
7. Prior to applying Sikaflex glue or Silicon to your table base, make sure everyone is ready to lift your tabletop after application and your non-lifting helper is ready to guide you.
8. Apply the Sikaflex glue or Silicon to the top of your table base/s.
9. Carefully lift your tabletop and gently place down onto your table base following the instruction from your non-lifting helper who is watching the underside of your tabletop to ensure your base and the markings on the underside of your tabletop align.
10. Once down, quickly grab your measuring tape and check the tabletop overhang on each side is equal.
11. Check the table is level. Use a level to ensure that the tabletop is flat and not tilted in any direction.
12. Move slightly if needed before your Sikaflex glue or Silicon dries ensuring it sits evenly and securely. The weight of the tabletop should help it settle into place.



13. Clean the surface of the tabletop using a clean cloth.
14. Allow the assembled table to rest and set in place for the recommended curing time specified by Sikaflex Glue or Silicon. During this time, avoid placing any heavy objects on the table or subjecting it to excessive stress.
15. Well done! You have just assembled your new concrete dining table!