



-INSTALLATION- INSTRUCTIONS




LP ADVENTURE LIFT KIT



SUBARU CROSSTREK 2018-2021

CONGRATULATIONS FOR YOUR NEW LP AVENTURE LIFT KIT!

If you have any question or need assistance
during the installation please
contact our team. You
can find the information
on the last
page.



IN
THE
BOX



IN THE BAGS

1



2



3



4



5





NECESSARY TOOLS

1. - We recommend the use of a lift
2. - Jack stand to support the sub-frame
3. - Ratchet
4. -12mm Socket
5. -14mm Socket
6. -17mm Socket
7. -19mm Socket
8. - 22mm Socket
9. -10mm Wrench
10. -12mm Wrench
11. - 14mm Wrench
12. -17mm Wrench

1

REMOVE WHEELS



2

REMOVE TOP PLATE NUTS







3

REMOVE TRUNK INTERIOR





4


REMOVE REAR TOP PLATE NUTS





5

UNBOLT SWAY BAR LINK





6


UNBOLT KNUCKLE



7

UNCLIP ABS SENSOR LINE






8

UNBOLT BRAKE LINE BRACKET



9

UNBOLT KNUCKLE



10

REMOVE FRONT SUSPENSION ASSEMBLY



11

INSTALL TOP PLATE SPACERS



USE A SCREW DRIVER OR PRYBAR TO HELP SUPPORT THE SUSPENSION DURING INSTALLATION



12

INSTALL SWAYBAR LINK SPACER





13

INSTALL BRAKE LINE BRACKET EXTENSION






14

RE INSTALL SUSPENSION ASEMBLY



FRONT RIGHT

FRONT LEFT



15

RE INSTALL LOWER STRUT BOLTS



16

RE SECURE THE SWAY BAR LINK TO THE EXTENDED MOUNT



17

RE INSTALL BRAKE LINE BRACKET



18

RE CLIP ABS LINE




19

REMOVE GAS TANK PLASTICS



20

UNCLIP FENDER PLASTIC SPLASH GUARD



21

REMOVE HAND BRAKE CABLE BRACKET




22

REMOVE BRAKE LINE BRAKET



23

REMOVE TWO BOLTS FROM SUBFRAME BRACKET



24

REMOVE SUBFRAME BOLTS



25

TEMPORARILY INSTALL THE SUPPLIED SUBFRAME BOLTS TO HELP KEEP EVERYTHING CENTERED



26


USE A JACK TO SUPPORT THE REAR DIFF



27

UNBOLT SUBFRAME BOLTS





28

SLOWLY LOWER THE SUB FRAME DOWN JUST ENOUGH TO BE ABLE TO INSTALL THE SUB FRAME SPACERS



29

INSTALL SUB FRAME SPACERS



30

INSTALL THE SUPPLIED BOLTS WITH THE FACTORY PLATE INTO THE REAR OF THE SUB FRAME





SNUG UP BUT DO NOT TIGHTEN THE BOLTS COMPLETELY



31

REMOVE THE TEMPORARY BOLTS FROM THE FRONT OF THE REAR SUB FRAME



32

INSTALL THE SUB FRAME SPACERS



33

THREAD IN THE SUPPLIED SUB FRAME BOLT ALONG WITH THE FACTORY SUB FRAME SUPPORT PLATE



34

INSTALL THE SUB FRAME SUPPORT PLATE SPACER





35

INSTALL BRAKE LINE BRACKET SPACER



36

INSTALL THE BRAKE LINE TO THE BRAKE LINE SPACER
*MAKE SURE TO ANGLE THE BRAKE LINE BRACKET TOWARDS
THE INSIDE OF THE VEHICLE



37

INSTALL LOWER BRAKE LINE BRACKET SPACER



38

INSTALL THE LOWER BRAKE LINE BRACKET
ONTO THE SPACER





USE A SCREW DRIVER TO KEEP THE BRACKET FROM TURNING WHEN YOU TIGHTEN THE BOLT DOWN.




39

INSTALL BRACKET SPACER FOR THE SPLASH GUARD



40

REMOVE TWO BOLTS FOR THE SWAY BAR MOUNT



41

REMOVE THE NUTS THAT HOLD THE SWAY BAR TO THE MOUNT AND REMOVE THE MOUNT





42

INSTALL THE SPACER FOR THE SWAY BAR MOUNT





43

RE INSTALL SWAY BAR MOUNT TO THE SWAY BAR




44

RE INSTALL SWAY BAR MOUNT TO THE VEHICLE



45


SWAP OUT THE FACTORY MUFFLER HANGERS FOR THE INCLUDED EXTENDED HANGERS





46

RE INSTALL GAS TANK PLASTICS



47

REMOVE LOWER KNUCKLE AND SHOCK BOLTS





48

REMOVE REAR SHOCKS



49

INSTALL THE REAR TOP PLATE SPACERS.



50

RE INSTALL REAR SHOCK ASSEMBLY



51

RE INSTALL LOWER BOLTS FOR SHOCKS AND KNUCKLES



52

FINAL TIGHTEN ALL HARD WARE



53

RE INSTALL AND TIGHTEN TOP STRUT NUTS AND THEN YOU CAN RE INSTALL THE TRUNKS INTERIOR



54

RE INSTALL WHEELS



INSTALLATION COMPLETE!



▼
NOTES:

****Tighten all the bolts to the manufacturer's specifications with a Torque Wrench****

**Double check your work.
Reinstall the wheels and be sure to tighten
the nuts with a torque wrench.**

Wheel alignment is required after installation.

**Products warnings:
<https://lpaventure.com/pages/products-warnings>**

**Limited product warranty:
<https://lpaventure.com/pages/limited-prod->**



**You have completed the installation.
Thank you for your interest
in our products.**

**For all requests, information or
assistance: Contact our team
by phone at
1 (866) 562-1316**

**We are available Monday to Friday
Between 8AM and 5PM (EST).**

**Or by email at :
SALES@LPAVENTURE.COM
WWW.LPAVENTURE.COM**

NOW, ENJOY THE RIDE!