BEYOND SHIPLAP BY NINTH & VINE

QUICK START INSTALLATION INSTRUCTIONS

(see www.ninthandvine.com/pages/tutorials for our full, in depth instructions/tutorials)

MINIMUM TOOLS

- 1 TAPE MEASURE
- 2 LEVEL
- 3 PENCIL
- 4 DUST MASK
- **5 EYE PROTECTION**
- 6 CUTTING TOOL:

SPEED SQUARE AND HAND SAW MINIMUM

7 J ROLLER:

IF INSTALLING WITH ADHESIVE TAPE



















2 PERSON INSTALLATION RECOMMENDED

WALL PREPARATION

- Wall surface must be clean, dry, structurally sound, flat, free of significant texture.
- If your wall is heavily textured, the (optional) supplied foam tape may be insufficient.

FLEXIBLE INSTALLATION OPTIONS FOR SHIPLAP (BRICK BELOW)

(Check your base moulding to make sure it is level)

Peel-and-stick adhesive tape (Recommended for most installations exept brick)

- The adhesive tape is very strong. Before you remove the protective backing for final installation, be sure to test fit each plank as you go to assure proper fit.
- . After test fitting, remove the tape backing and apply to the wall. Use popsicle sticks, or nickels to create gaps between planks if desired. Use a J roller every few rows to activate the pressure sensitive adhesive
- ' tape. This step is very important to assure proper adherence.
- . Edges & Corners: we recommend wood or metal square edge moulding trim to finish. Paint or stain trim pieces as desired to match or compliment your planks.

Additional BRICK Instructions

- Start your first row in the bottom left corner of your wall.
- · The flat mortar joint should be facing down towards the molding.
- Cut ~7.5 inches off the left side of your first piece so you have a whole brick on top, and a half brick on the bottom. This will help you keep a staggered brick pattern on each subsequent row.
- Dry fit each each plank before final install.
- Place the bottom edge of the plank against the wall, slide it into position, then press the adhesive tape against the wall.
- With the first plank in each new subsequent row be sure to stagger the brick pattern evenly.
- If you wish to hide more of the seams you can use a 'Sanded Caulk' that closely matches the mortar color. You can find it at your local home improvement store.

BEYOND SHIPLAP BY NINTH & VINE

QUICK START INSTALLATION INSTRUCTIONS

(see www.ninthandvine.com/pages/tutorials for our full, in depth instructions/tutorials)

Other installation options

See our full tutorials at www.ninthandvine.com/pages/tutorials for other installation options such as using construction adhesive (glue), or finishing nails.

MAKING CUTS

- Use a measuring tape and speed square to mark the desired length of your board.
- Flexible cutting options: Miter (chop) saw is optimal. If you do not have a miter saw a hand saw will suffice use a speed square or miter box as a guide for a straighter cut.

CUTTING PLANKS/PANELS LENGTHWISE

- Test fit the plank where it will be installed.
- · Using a pencil mark both ends of the plank where it needs to be cut.
- ' Next use a straight edge or chalk line to connect your two marks.
- * We recommend using a Circular Saw or Table Saw to cut the plank lengthwise.

ADVISEMENTS

- Warning: Wood dust is known to the State of California as a Carcinogen.
 Wear protective equipment while cutting and installing wood products.
- . Warning: Wood is flammable.
 - Do not install this product near open flame or heat source such as a fireplace or furnace.
- . This product is not to be installed as a floor.
- . This product is not intended for installation in very damp or wet areas.
- . This product is made of recycled wood and thereby susceptible to changes in temperature and humidity.
- . This product is for interior use only. This product may be used for ceiling applications as long as you adhere to local building codes for installation procedures and restrictions.

