



## SilentWool Floor with Breathable paper Acoustic underlay for use under timber flooring



Made from 100% Pure Sheep Wool



SilentWool Floor acoustic underlay with Breathable paper can be used under solid timber floors, laminate floors, and parquet floors. It can be installed upon concrete floors as well as OSB / MDF boards and is suitable for use with underfloor heating.

Thickness 3mm

Roll Length 25m

Roll Width 1m

Roll area 25m<sup>2</sup>

Footfall sound improvement: bis 21 DB

**Tools required:** Scissors, wide moisture-resistant sticky tape, measuring tape and marking pen.

**Preparation :** The sub floor must be thoroughly clean and dry. When setting on a concrete floor, ensure surface is even and free from imperfections that may damage the floor being installed.

**Installation:** By design, SilentWool Floor will unroll with the paper layer on top. Install with the paper side facing up. At the walls, take edges of the roll up the wall by 2cm to avoid sound bridging. Cut around any obstacles using the measuring tape and marking pen for accuracy. Side-by-side sheets should be joined with sticky tape and not overlapped to avoid an uneven finish.

Install the timber floor directly onto this paper side of the pure wool acoustic underlay. The paper will not only ensure an even install but will also protect the SilentWool Floor.

Return to the floor edges once complete and fold the underlay behind itself to further insulate from the walls.



SheepWool Insulation - Unit 1, Railway Business Park Rathdrum, Co. Wicklow

Ph : 0404 46100 [www.sheepwoolinsulation.com](http://www.sheepwoolinsulation.com)

UK: Ph : 0871 218 5218 [uk@sheepwoolinsulation.com](mailto:uk@sheepwoolinsulation.com)