



HEADBOARD MOUNTING INSTRUCTIONS

Congratulations on your headboard purchase!

To ensure a perfect fit to your bed frame, your David Francis headboard is not pre-drilled. Hardware is included for your convenience.

YOU WILL NEED THE FOLLOWING

- POWER DRILL 
- STANDARD, 1/4" DRILL BIT 

THIS KIT INCLUDES THE FOLLOWING

- EIGHT (8) WASHERS 
- FOUR (4) 2" LONG, 1/4" THICK BOLTS 
- FOUR (4) WING NUTS 

ATTACHMENT INSTRUCTIONS

1. Place the metal bed frame against the headboard
2. Use a pencil to mark the holes on the bed frame (two on each leg)
3. Remove the bed frame and set aside
4. Using a standard 1/4" drill bit, drill into the 4 pencil marks on the headboard legs
5. Place the bed frame against the newly drilled holes
6. Insert the washers into the bolts
7. Insert the bolts through the bed frame and into the headboard legs
8. Secure with the wing nuts

As an alternative, these headboards can be mounted/hung on the wall.

