



HEADBOARD MOUNTING INSTRUCTIONS

Congratulations on your headboard purchase!

How to attach a David Francis Furniture headboard to a bed frame.

YOU WILL NEED THE FOLLOWING:

- Drill
- Standard, 1/4" drill bit
- (4) - 2" long, 1/4" thick bolts
- (8) washers
- (4) wing nuts

ATTACHMENT INSTRUCTIONS:

1. Place the metal bed frame against the headboard
2. Use a pencil to mark the holes on the bed frame (two on each leg)
3. Remove the bed frame and set aside
4. Using a standard 1/4" drill bit, drill into the 4 pencil marks on the headboard legs
5. Place the bed frame against the newly drilled holes
6. Insert the washers into the bolts
7. Insert the bolts through the bed frame and into the headboard legs
8. Secure with the wing nuts

As an alternative, these headboards can be mounted/hung on the wall.

