

HOW TO Install a CPAP front on Voron Stealthburner

Difficulty **Easy**

Steps **6**

Time Required **5 to 10 min**

Sections **1**



INSTRUCTIONS GUIDE

This guide is designed to be a reference manual for the installation of a CPAP front on the Voron Stealthburner platform. Follow the instructions below or, if you prefer to watch a YouTube video with the same instructions, use the provided link below or the YouTube icon to the right:

<https://youtu.be/ASzzKNpuFa8>



01 Add your LED diffuser of choice



02 Add your LED harness



03 Insert the 4010 hotend cooling fan



04 Place the CPAP hose mount on the top and add the four M3x6 FHCS



05 Pass your fan and LED wires through



06 Add your screws for the front, make sure the upper ones are M3x16 SHCS if you're using the LGX lite

IT'S DONE! TAKE GOOD CARE OF IT

Make sure the CPAP tube doesn't kink anywhere. It can take a beating, but be careful not to force any twisting or similar. If you feel you want to secure the hose further then add some zipties around the pipe mounts.

HOW TO GET HELP

We are available to help you with any questions or issues you may have. Simply go to our website where you can access our customer support and send us your questions or follow the provided link:

https://www.bondtech.se/contact/#tab_technical-support-requests

