

WWW.RALLY-RAIDPRODUCTS.CO.UK

**RALLY
RAID**
PRODUCTS:CO.UK
PRODUCTS:CO.UK

**REAR RACK
FITTING MANUAL**



WWW.RALLY-RAIDPRODUCTS.CO.UK

1. Remove the rear mudguard from tail of bike by removing all bolts.
2. Ensure all wires that pass through the tail section are placed correctly and will not foul the threaded insert (as shown)



3. If your rear mudguard does not have the required holes already, using a 19mm drill, locate the markings on the underside of the mudguard and drill the four holes. (as shown)
4. Replace mudguard onto bike and ensure all threaded inserts are clear before continuing.



5. Fit spacers provided, using shorter ones at the rear
- Note : do not use threadlocking products on these inserts, it may damage them.**
6. Fit m8x60 countersink screws and washers ensuring they are tight

