

## Replacement Lower Tank Sleeve Fitting Instructions-RRP 053

1. Remove rear exhaust shield, disconnect silencer from front pipe (undo Allen screw and remove spring).
2. Using an air wrench, or cordless impact gun, with a 10mm socket, remove one of the M8 bolts from the Lower Sleeve. Grease the thread on the bolt and replace, then remove M8 bolt from other side.
3. Go back and remove the first bolt, this should work, but sometimes the sleeve will just spin in the tank. If this happens, keep repeating the operation until they both are removed.
4. Just lift the rear tank unit up a couple of inches and this will expose the sleeve, knock it out with a suitable drift.
5. Lightly grease the new sleeve and insert into the tank, ensuring the polyurethane bushes do not get knocked out.
6. Gently lower the tank so that the sleeve fits between the frame, whilst guiding the silencer onto the front pipe. Then insert the M8 x 140 CHS with washer through the frame and sleeve, and fit M8 Nyloc and washer on opposite side and tighten securely.
7. Tighten silencer clamp, replace spring & shield (use loctite on M5 torx screws).