

Ri1000 Mask - Flat/No Seam Installation Diagram

Placement template URL: www.customplatens.com/Downloads

Use the coupon code **MFP** to download the template.

Contents: 7 M4x16mm Phillips screws, 1 M4x10mm Phillips screws, 1 Alignment Pin, 1 Alignment Screw, 1 Nut, 3 Platen attachments, 1 Platen base

