



**A L L I E D**

### K-Edge Echo Mount Instructions

1. Start by removing the two front faceplate bolts, loosen them equally by switching sides every few turns.
2. Setup the new mount with the longer bolts and slide on the washers.
3. Snug the bolts down equally by switching sides every few turns.
4. Once any pressure is felt, switch to your torque wrench.
5. Torque each side to 5nm. You will need to repeat this process checking both bolts several times until both are equally torqued to 5nm.
6. Add the computer mount to the knuckle with the two matching black M2.5 bolts with blue Loctite and tighten to 3nm.
7. Adjust the angle to your preference.
8. If you're a Wahoo user, swap the receiver to the grey plate using the already installed M2 bolts, add-in, and tighten the grey Wahoo plate to .88nm.

