

**ASSEMBLY INSTRUCTIONS FOR
"ROBAX" DUO BUNK SET**

Thank you for choosing a "Robax" bunk.

Please read the following instructions before assembly.

YOU SHOULD HAVE:

- 2 BUNDLES OF SIDE PANELS & GUARD RAILS
- 1 LADDER
- 1 PAIR OF LONG ENDS
- 1 PAIR OF SHORT ENDS
- 2 PIECE DOUBLE SLATS
- 1 SINGLE SLAT

THE BAG OF FITTINGS HAS:

- 13 x 100MM CONNECTING BOLTS
- 2 x 80MM CONNECTING BOLTS
(to attach guard rail support)
- 15 x 20MM CROSS DOWELS
- 2 SPACER WASHERS
- 2 SHORT SILVER SCREWS
- 16 LONG SCREWS
- 1 ALLEN KEY
- 6 SPACER DOWELS

TO COMPLETE ASSEMBLY YOU WILL NEED A SCREWDRIVER.

1. INSERT CROSS DOWELS INTO BLIND HOLES IN SIDE PANELS AND GUARD RAILS ALIGNING SO THE THREADED HOLE IS HORIZONTAL.
2. INSERT 2 SIDE PANELS [with mounting strips near the middle] AND CENTRE RAIL INTO THE DOUBBLE (BOTTOM) ENDS AND TAP HOME WITH YOUR HAND.
3. PUSH **LONG** BOLT THROUGH HOLES IN POST AND SCREW INTO CROSS DOWELS. [use screwdriver to hold cross dowels straight]
4. TIGHTEN WITH ALLEN KEY. DO NOT OVERTIGHTEN.
5. INSTALL SLAT. FIX LONG SCREWS PROVIDED THROUGH HOLES IN SLATS TO SIDE PANEL SUPPORTS AND CENTER RAIL.
6. MOVE BOTTOM FRAME INTO PLACE IN ROOM; FIT 4 DOWELS TO TOP OF POSTS AND TOP RAIL END WITH ROUND LEVELING WASHERS HERE AS WELL.
7. REPEAT STEPS 1 TO 5 FOR TOP SINGLE FRAME [using panels with strips at bottom] AND INCLUDE FULL LENGTH GUARD RAIL ON WALL SIDE AND SIDE PANEL WITH HOLE IN IT ON THE OTHER.
8. LIFT TOP FRAME ONTO BOTTOM FRAME VIA THE DOWELS, WITH FULL LENGTH GUARD RAIL ON WALL SIDE. ATTACH SHORT GUARD RAIL TO POST END. FIT GUARD RAIL SUPPORT TO SHORT GUARD RAIL AND SIDE PANEL WITH HOLE IN IT USING 2 DOWELS AND 2 **SHORT** BOLTS.
9. ATTACH LADDER BY HOOKING OVER SIDE PANEL AND SCREW FROM INSIDE WITH 2 SHORT SILVER SCREWS PROVIDED,
10. THE BUNK IS NOW COMPLETE.

ONLY USE THE BUNK IF **ALL** PIECES, **BOLTS AND SCREWS** MENTIONED ABOVE ARE IN PLACE.

AFTER A SETTling DOWN PERIOD RE-TIGHTEN ALL BOLTS AND SCREWS.

Robax Products Ltd, PO Box 1720, Invercargill