

2a

**ASSEMBLY INSTRUCTIONS FOR
"ROBAX" LOFT BED.**

***Thank you for choosing a "Robax" Loft Bed.
Please read the following instructions before assembly.***

YOU SHOULD HAVE: 1 PAIR OF LONG ENDS
 1 SLAT GRID
 1 BUNDLE OF 2 SIDE PANELS &
 3 GUARD RAILS

BAG OF FITTINGS HAS: 10 x 80MM CONNECTING BOLTS
 6 LONG SCREWS
 10 x 20MM CROSS DOWELS
 1 ALLEN KEY

TO COMPLETE ASSEMBLY YOU WILL NEED A SCREWDRIVER.

1. INSERT CROSS DOWELS INTO SIDE PANELS AND GUARD RAILS ALIGNING SO THE THREADED HOLE IS HORIZONTAL.
2. INSERT 2 SIDE PANELS INTO ONE END AND TAP HOME WITH YOUR HAND.
3. PUSH CONNECTOR BOLT THROUGH HOLE IN POST AND SCREW INTO CROSS DOWELS ABOUT HALF WAY.
4. INSERT 2 SIDE PANELS INTO OTHER END AND TAP HOME WITH YOUR HAND.
5. PUSH CONNECTOR BOLT THROUGH HOLE IN POST AND SCREW INTO CROSS DOWELS ABOUT HALF WAY.
6. INSTALL 2 UPPER GUARD RAILS AND 1 LOWER GUARD RAIL IN SAME WAY.
7. TIGHTEN WITH ALLEN KEY. DO NOT OVERTIGHTEN.
8. INSTALL SLAT. FIX LONG SCREWS PROVIDED THROUGH SLATS TO SIDE PANEL SUPPORTS (3 ALONG EACH SIDE).
9. AFTER A SETTLING DOWN PERIOD RE-TIGHTEN ALL BOLTS AND SCREWS.
10. THE BED IS NOW COMPLETE. ONLY USE IF ALL PIECES, BOLTS AND SCREWS MENTIONED ABOVE ARE IN PLACE.

Robax Products Ltd, PO Box 1720, Invercargill