



Installing a single panel screen



Step 1

Position your bottom row of screen clips at the left and right. Allowing two inches before the corners prevent the clips from catching your eye. Use the double sided positioning tape on the back of the clips. Once they are level and straight, nail them into place. Place the screen in the channel created by the screen clips.

Step 2

Have someone hold the screen in place (place pressure along the edges where there are wooden supports beneath the paper/silk). Use a tissue or soft cloth to protect the surface from oils on your hands. Slide the top clip over the top edge, aligned with your bottom clips.

The installation is complete!