

HOW TO: NSTALL THE SAYITSIGN **ON THE BACKOF YOUR CAR**

1. When you receive your SayItSign take it out of the box



PART 1 is the base unit.

PART 2 will arrive already attached to the back of the sign.

PART 3 will arrive already attached to the front of the sign.



PART 4 will be used with **PART 5** to secure the license tag.

PART 5 is the license tag lighting unit.





PART 6 is the stabilizer. It will reduce the vibration of the sign.



2. Install batteries into the back of Part 5 with a phillips head screwdriver. Put 3-AA batteries (included) into the correct positions as instructed in the battery compartment. When finished, put the cover back on and tighten screws. Now you are ready to install it on your vehicle.



3. Remove license plate from vehicle with appropriate tool. Usually, a phillips head screw driver is needed.



4. Carefully inspect the screws and screw holders to make sure they are in good shape and operable. Meaning, they are not dry rotted and the screws are fastening and unfastening properly. 5. Before installing Part 1- Loosen Wingnuts B, C, D so that you are able to rotate mounting flange down.

This will give you more room to use your screwdriver or tool.





6. Hold Part 1 in place and put the two screws through Holes A and B back into the license plate holes. Be sure to put the two washers that are provided onto the screws before tightening. Reuse the existing screws that are being used currently on the vehicle. Tighten the two license plate screws snugly. Do not overtighten and strip screws.

7. Once tightened and in place, rotate flange to the correct angle so that the sign will be in a viewable position. Once in that position, tighten Wingnuts B, C, and D completely, making sure that Wingnut B is in the LOCK position. Do not use a tool to overtighten, just tighten as good as you can using your fingers.



8. Slide sign onto the mounting flange and then tighten knob securely.





9. Now that the sign is on, we need to take Wingnut A (provided) and install it into the Wingnut A hole. Tighten it completely and place it in the LOCK position.

10. When taking your sign off, take Wingnut A out completely. This will allow you to slide off the sign freely.



11. Now it is time to put license tag into holder. Take Part 4 and take off Wingnuts. Put the two screws into the Holes A and B on Part 5. Then put license tag onto the screws as well. Now put the Wingnuts back on and tighten firmly.





13. Last step is to hold spacer up to the sign and measure distance between sign and bumper. Mark with your finger and cut the spacer using a utility knife. (BE CAREFUL not to cut yourself) You should cut the spacer approx ¼ inch more than the distance.

12. Slide license holder onto sign and tighten the knob fully. Turn ON/OFF switch to the ON position.



14. Now peel off the sticker and place sticky side on the back of the sign. Place in a location that allows contact with bumper or car to stabilize sign (Usually the stabilizer is placed behind the license plate).

IMPORTANT! Push license plate and sign into the bumper to put pressure on the stabilizer and strengthen the adhesive bond.



The sign is complete. Make sure to check on all screws regularly to make sure they are snug. Also monitor the sign regularly.



THE SIGN IS PLACED IN THE NO WIND ZONE OF A CAR

