

### **Rockwell Boot Guard Instructions**

1. Bolt bottom of guard to the bottom of the Rockwell knuckle.
2. Position “batwing” face of guard on the small tab of the bottom plate and hold it at an angle so that the side of the boot guard aligns correctly. It may help to have an assistant as an extra set of hands to hold everything in place. Tack weld the face to the bottom.
3. Verify that the sides align properly and tack weld them in place.
4. Remove tacked assembly and weld all the seems inside and out.
5. Reinstall assembly using longer bolts with the stock dust cap beneath it to retain the grease fitting. Final product will look like this:

