

2012 - 2018 Dodge RAM Crew Cab

(one piece first row floor mat)

TRIM LINE INSTRUCTIONS: Floor Mat trim patterns vary per vehicle make and model.

* Please ensure you are 100% satisfied with your purchase before *
trimming, as this will void your return and warranty

STEP 1:

Remove Floor Mat from box and allow it to lay out in a warm area. This allows the liner to regain it's custom shape after being rolled up for shipping.



BEFORE

Optional trim line for vehicles with front bench seat cup holder.



AFTER



STEP 2:

Trim using sharp scissors or a carpenter's knife to cut along crevice in mat to remove area as shown to accommodate vehicles with front bench seat cup holders.