

## 2007 - 2014

# Tahoe/Suburban/Yukon/Denali & XL Models

**TRIM LINE INSTRUCTIONS:** Floor Mat trim patterns vary per vehicle make and model.

\* Please ensure you are 100% satisfied with your purchase before \*  
trimming, as this will void your return and warranty

Optional trim line for  
vehicles with front bench seat.



### STEP 1:

Remove Floor Mat from box and allow it to lay out in a warm area. This allows the liner to regain it's custom shape after being rolled up for shipping.



### STEP 2:

Trim using sharp scissors or a carpenter's knife to cut along crevice in mat to remove area at top for vehicles with front bench seat.



Smartliner USA



smartlinerusa



Smartliner-USA