

2007 - 2014

Tahoe/Suburban/Yukon/Denali & XL Models

TRIM LINE INSTRUCTIONS: Floor Mat trim patterns vary per vehicle make and model.

* Please ensure you are 100% satisfied with your purchase before *
trimming, as this will void your return and warranty

Optional trim line for
vehicles with front bench seat.

BEFORE



STEP 1:

Remove Floor Mat from box and allow it to lay out in a warm area. This allows the liner to regain it's custom shape after being rolled up for shipping.

AFTER



STEP 2:

Trim using sharp scissors or a carpenter's knife to cut along crevice in mat to remove area at top for vehicles with front bench seat.



Smartliner USA



smartlinerusa



Smartliner-USA