

2011 - 2020 JEEP Grand Cherokee/Dodge Durango

TRIM LINE INSTRUCTIONS: Floor Mat trim patterns vary per vehicle make and model.

* Please ensure you are 100% satisfied with your purchase before *
trimming, as this will void your return and warranty

STEP 1:

Remove Floor Mat from box and allow it to lay out in a warm area. This allows the liner to regain it's custom shape after being rolled up for shipping.



BEFORE

Trim area for vehicles with second row bucket seats and center console



AFTER

STEP 2:

Trim using sharp scissors or a carpenter's knife to cut along crevice in mat to remove area as for vehicles equipped with the super console.



Smartliner USA



smartlinerusa



Smartliner-USA