

2007 - 2010 JEEP Wrangler Unlimited

TRIM LINE INSTRUCTIONS: Floor Mat trim patterns vary per vehicle make and model.

Please ensure you are 100% satisfied with your purchase before
trimming, as this will void your return and warranty

STEP 1:

Remove Floor Mat from box and allow it to lay out in a warm area. This allows the liner to regain it's custom shape after being rolled up for shipping.



BEFORE

Do NOT cut mat if your vehicle is NOT equipped with subwoofer.



AFTER

STEP 2:

Trim using sharp scissors or a carpenter's knife to cut along crevice in mat to remove area for vehicles equipped with optional factory subwoofer.



smartlinerusa



Smartliner-USA



Smartliner USA