

# 2007-2017 FORD Expedition EL/LINCOLN Navigator L

**PLEASE  
FOLLOW  
THE TRIM  
INSTRUCTIONS,  
IF YOUR CAR  
HAS A CENTER  
CONSOLE.**

**TRIM LINE INSTRUCTIONS:** Floor Mat trim patterns vary per vehicle make and model. If you need assistance with your install or have any questions, please call the Manufacturer **407-704-6740**, Monday - Friday between the hours of 7 a.m. - 4 p.m. (EST).

## STEP 1

*Remove Floor Mat from box and allow it to lay out in a warm area. This allows the mat to regain it's custom shape after being rolled up for shipping.*



## STEP 2

*Use sharp scissors or a carpenter's knife to cut along crevice in mat to remove area at top of mat to accommodate vehicles with a center console.*



Smartliner USA



smartlinerusa



Smartliner-USA