

2007 - 2017 Chevy Equinox / GMC Terrain

TRIM LINE INSTRUCTIONS: Floor Mat trim patterns vary per vehicle make and model.

Please ensure you are 100% satisfied with your purchase before
trimming, as this will void your return and warranty

Trim area is provided at the
top of Cargo Liner for vehicles
with sliding 2nd row

STEP 1:

Remove Floor Mat from box and allow it to lay out in a warm area. This allows the liner to regain it's custom shape after being rolled up for shipping.



AFTER



STEP 2:

Trim using sharp scissors or a carpenter's knife to cut along crevice in mat to remove area for vehicles equipped with a sliding 2nd row.



Smartliner USA



smartlinerusa



Smartliner-USA