

# 2015 - 2018 Mercedes Benz C-Class Series

**TRIM LINE INSTRUCTIONS:** Floor Mat trim patterns vary per vehicle make and model. If you need assistance with your install or have any questions, please call the Manufacturer **407-704-6740**, Monday - Friday between the hours of 7 a.m. - 4 p.m. (EST).

## STEP 1

*Remove Cargo Liner from box and allow it to lay out in a warm area. This allows the liner to regain it's custom shape after being rolled up for shipping.*



## STEP 2

*Use sharp scissors or a carpenter's knife to cut along crevice in mat to remove area to accommodate vehicles with optional cargo net.*

### MAT SHOWN TRIMMED FOR VEHICLES WITH OPTIONAL CARGO NET



smartlinerusa



Smartliner-USA



Smartliner USA