

INSTALLATION INSTRUCTIONS FOR SAFE WEDGE CLUB CAR

PART NUMBER: SW CLUB CAR



PROUDLY DESIGNED, MANUFACTURED AND DISTRIBUTED IN THE U.S.A BY
FIVE STAR FABRICATING, INC.
36728 89TH STREET | TWIN LAKES, WI 53181

REVIEW INSTRUCTIONS BEFORE BEGINNING INSTALLATION

COMPLETE KIT CONTENTS

**SAFE WEDGE
POLYCARBONATE**



**SAFE WEDGE E-Z-GO RXV
MOUNTING BRACKET**



**BRACKET-TO-CART
MOUNTING HARDWARE KIT**



- Kit Contents:
- (4) 1/4-20 x 2-1/2" Bolt
 - (4) 1/4-20 Flange Nuts
 - (4) Spacers

**POLYCARBONATE-TO-BRACKET
MOUNTING HARDWARE KIT**



- Kit Contents:
- (4) 10/32 NF x 1-1/2" Bolts
 - (4) 10-L Flat Washers
 - (4) Rubber Washers
 - (4) 10/32 Lock Nuts
- *Extras are included*

STEP 1: Remove bolts attaching roof to the frame of the cart with a 10mm wrench.



WHAT YOU WILL NEED FOR INSTALL:

- Bracket-to-Cart Mounting Kit (Included)
- Polycarbonate-to-Bracket Mounting Kit (included)
- 10mm Socket Wrench
- 10mm Crescent Wrench
- 3/8" Crescent Wrench
- 1/8" Allen Wrench

STEP 2: Position bracket into place, aligning with mounting holes in roof/frame.



STEP 3: Attach Bracket



STEP 3A: Place spacer between bracket and roof mount. Insert 1/4-20 x 2-1/2" bolt through spacer, roof, and frame with the head of the bolt positioned toward the inside of the cart.



STEP 3B: Replace washer and affix 1/4-20 flange nut. Use 10mm wrenches to tighten.



STEP 3C: Repeat steps 3A and 3B for remaining Bracket-to-Cart bolts.

STEP 4: Attach Polycarbonate to Bracket



STEP 4A: Remove protective masking from polycarbonate.



STEP 4B: At leading edge of polycarbonate, place 10/32 NF x 1-5/8" bolt through polycarbonate with 10-L flat washer on the same side as the bolt head. Affix the rubber washer on the opposite side of the polycarbonate.



STEP 4C: Repeat step 4B at the trailing edge of the polycarbonate (4th hole from the front of the partition).



STEP 4D: Attach polycarbonate by placing bolts through holes on bracket.



STEP 4E: Place remaining bolts attaching polycarbonate to bracket. Metal 10-L washer goes between bolt head and polycarbonate. Rubber washer is positioned between polycarbonate and bracket.



STEP 4F: Affix and tighten 10/32 Lock nuts using 1/8" allen wrench and 3/8" crescent wrench.

IMPORTANT

DO NOT OVERTIGHTEN SCREWS!

» Polycarbonate windows must be able to expand and contract. Overtightening screws will crack the window around the mounting holes.

DO NOT USE LIQUID THREADLOCKER!

» It will cause stress cracking on the polycarbonate.

Approved sealants for polycarbonate windows:

- 3M Ultrapro • Dow Corning 795 • Mumentive/GE SCS2000
- SilPruf • 3M Super Silicone Sealant • Dow Corning 995

