INSTALLATION INSTRUCTIONS FOR

SAFE WEDGE E-Z-GO RXV

PART NUMBER: SW EZGO RXV



PROUDLY DESIGNED, MANUFACTURED AND DISTRIBUTED IN THE U.S.A BY FIVE STAR FABRICATING, INC. 36728 89TH STREET | TWIN LAKES, WI 53181

REVIEW INSTRUCTIONS BEFORE BEGINNING INSTALLATION



WHAT YOU WILL NEED FOR INSTALL:

Polycarbonate-to-Bracket Mounting Kit (included) 15mm Socket Wrench 15mm Crescent Wrench 3/8" Crescent Wrench 1/8" Allen Wrench









STEP 1: Remove cart's roof by removing the bolts attaching the roof to the frame of the cart with a 15mm wrench.

STEP 2: Assemble the Safe Wedge



STEP 2D: Tighten lock nut using

1/8" allen wrench and 3/8" wrench

STEP 2A: Remove protective masking from polycarbonate.



STEP 2B: Place the metal washer between the bolt head and polycarbonate. Place the rubber washer between the polycarbonate and bracket. Insert the bolt through the polycarbonate and bracket.



STEP 2E: Repeat steps 2b-2d for remaining polycarbonate-to-bracket bolts



STEP 2C: Affix the lock nut on the opposite side of the bracket

» Polycarbonate windows must be able to expand and contract. Overtightening screws will crack the window around the mounting holes.

DO NOT USE LIQUID THREADLOCKER!

» It will cause stress cracking on the polycarbonate. Approved sealants for polycarbonate windows:

• 3M Ultrapro • Dow Corning 795 • Momentive/GE SCS2000 SilPruf • 3M Super Silicone Sealant • Dow Corning 995





STEP 3: Place Safe Wedge assembly on cart allowing grooves to rest on frame.



STEP 4: Replace roof over Safe Wedge assembly.



STEP 5: Re-install frame-to-roof bolts. Tighten using 15mm wrench.