

# INSTALLATION INSTRUCTIONS FOR SAFE WEDGE YAMAHA DRIVE & DRIVE2

PART NUMBER: SW YAMAHA DR



PROUDLY DESIGNED, MANUFACTURED AND DISTRIBUTED IN THE U.S.A BY  
**FIVE STAR FABRICATING, INC.**  
36728 89TH STREET | TWIN LAKES, WI 53181

## REVIEW INSTRUCTIONS BEFORE BEGINNING INSTALLATION

### COMPLETE KIT CONTENTS

**SAFE WEDGE  
POLYCARBONATE**



**SAFE WEDGE E-Z-GO RXV  
MOUNTING BRACKET**



**POLYCARBONATE-TO-BRACKET  
MOUNTING HARDWARE KIT**



- Kit Contents:  
(4) 10/32 NF x 1-1/2" Bolts  
(4) 10-L Flat Washers  
(4) Rubber Washers  
(4) 10/32 Lock Nuts  
*\*Extras are included*

#### WHAT YOU WILL NEED FOR INSTALL:

- Polycarbonate-to-Bracket Mounting Kit (included)
- 1/2" Crescent Wrench
- 3/16" Allen Wrench
- 3/8" Crescent Wrench
- 1/8" Allen Wrench



**STEP 1:** Remove bolts at rear of cart's roof using 1/2" crescent and 3/16" allen wrenches.



**STEP 2:** Align bracket to holes in roof. Insert cart's bolts through the roof mounts and bracket.




**STEP 3:** Replace cart's acorn nuts and tighten.

**STEP 4:** Attach Polycarbonate Partition



**STEP 4A:** Remove protective masking from polycarbonate.



**STEP 4B:** At leading edge of polycarbonate, place 10/32 NF x 1-5/8" bolt through polycarbonate with 10-L flat washer on the same side as the bolt head. Affix the rubber washer on the opposite side of the polycarbonate.



**STEP 4C:** Repeat step 4B at the trailing edge of the polycarbonate (4th hole from the front of the partition).



**STEP 4D:** Attach polycarbonate by placing bolts through holes on bracket.



**STEP 4E:** Place remaining bolts attaching polycarbonate to bracket. Metal 10-L washer goes between bolt head and polycarbonate. Rubber washer is positioned between polycarbonate and bracket.



**STEP 4F:** Affix and tighten 10/32 Lock nuts using 1/8" allen wrench and 3/8" crescent wrench.



**IMPORTANT**

**DO NOT OVERTIGHTEN SCREWS!**

» Polycarbonate windows must be able to expand and contract. Overtightening screws will crack the window around the mounting holes.

**DO NOT USE LIQUID THREADLOCKER!**

» It will cause stress cracking on the polycarbonate.  
Approved sealants for polycarbonate windows:  
• 3M Ultrapro • Dow Corning 795 • Momenive/GE SCS2000  
SilPruf • 3M Super Silicone Sealant • Dow Corning 995

