

# Column Sentry FIT Installation



Position the 4 pieces of the Column Sentry FIT around the column. Slide 2 each together, until you have 2 equal sides.



Slide those "halves" toward each other, sliding the parts together or apart, until it fits the column tightly.



Wrap the finished column protector with the included 2-sided Velcro straps.



The Column Sentry FIT is set and ready for action.