



Knuckle Pod Mounts Installation Instructions

2017+ Ford Super Duty Applications

Tools Needed: The Driver side mount can be either welded on or bolted on with the use of a tap and die set.

- 11mm Wrench and Socket
- Drill and ¼ drill bit or drill bit set
- Drill punch or sharpie to mark holes

Parts Included:

- (1) Knuckle Pod Mount (driver side)
- (1) Knuckle Pod Mount (passenger side)
- (4) ¼” bolts with washers and nuts (Grade 8)



Installation:

1. Remove wheels for easier access to knuckles.
2. Locate the proper mount for the side you are working on (bend down flange will sit against the inside face of the knuckle).
3. Place the mount on a flat spot of knuckle in front of your ball joint and butt up the bent flange to the side of the knuckle.
4. Mark your two holes through the mount and drill out to ¼” or slightly over.
5. Install a washer on each bolt and pass it through the two holes and install your washers and locking nuts on the bottom.
6. Tighten snug or torque to 12 ft lbs.
7. Install lights and run wiring along the brake lines up through your fenders and into the engine bay.
8. Hook up to your choice of switch or switch panel and reinstall your wheels.





For any questions or concerns regarding installation please contact us at 209-407-1502 or email us at support@gatekeeperoffroad.com.