

GATEKEEPER OFF-ROAD

Knuckle Pod Mounts Installation Instructions

Can Am X3 2017+

Does not work with Factory Offset 6+1 Wheels

Tools Needed:

- Standard Socket Set
- 3/32 Rivet Tool for Logo Plate
- Torque Wrench

Parts Included:

- (2) Knuckle Pod Mounts
- (2) Support Brackets
- (2) Knuckle Pod Mount logos
- (4) Logo rivets
- (2) ¼ Stainless Bolts
- (2) ¼ SS Nylocks
- (4) ¼ SS Washers



Installation:

1. Install logos after painting brackets by using the supplied 3/32 rivets. Make sure the GK is right side up when installing.
2. Remove caliper bolts from the spindle on each side. You will be reusing the factory bolts. Pre-install one of the ¼ stainless bolts and washer into the small hole between the main mounting holes. This will make mounting the support bracket much easier.
3. Slide the Knuckle Pod Mount behind the brake line and bolt it to the caliper location using the factory caliper bolts. **TORQUE TO FACTORY SPEC.** (You must torque the bolts before installing the support bracket) (Loc-Tite may be required, see factory specs).



4. Install the support bracket using the pre installed stainless bolt and nylock nut. The brake line will sit in between the mounting bracket and support bracket. Be sure to line up the slotted holes on the tops of the brackets before tightening the $\frac{1}{4}$ nut.

When wiring your lights we recommend following the factory brake lines and using zip ties to secure the wire out of the way of being caught or snagged.

If you have aftermarket control arm skid plates you may need to trim the plastic depending on clearance.

It is your responsibility to cycle your suspension using a jack to make sure your lights clear on full droop and full bump while steering lock to lock before using this product.

Installation by a professional mechanic is recommended.

This product is not DOT approved and is intended for offroad use only. Install and use at your own risk.