



# Gatekeeper Off-Road

## TJ License Plate Relocation Installation Instructions

*97-06 Jeep TJ and LJ*

### Tools Needed:

- Standard socket Set (13mm socket)
- Basic wiring tools (wire strippers, heat gun or blow dryer)

### Parts Included:

- (1) License Plate Relocation Kit
- (1) ORO Liteplate Kit (Instructions included)
- (4) ¼"-20 x ¾" SS Bolts
- (4) ¼" SS Washers
- (4) ¼"-20 SS Nylock nuts

### Installation:

1. Remove the factory 13mm bolts from the stock tire carrier location. (Remove tire carrier if still installed on the vehicle).
2. Remove License plate from stock location and install it to your new frame using the provided ¼" hardware before mounting it on the vehicle.
3. Install the ORO Liteplate above license plate on the relocation bracket before mounting to the vehicle.
4. Reuse factory 13mm bolts to mount the relocation bracket on the vehicle.
5. Wire in your new Liteplate using the provided instructions.