

ALICE COMPRESSION STRAP INSTRUCTIONS



1. Position one of the female side release buckle (SRB) straps under the ALICE frame, above the horizontal cross bar. Ensure the plastic slider is positioned tightly against the bartacked webbing section.



2. Slide the angle-cut end through the plastic slider. Snug the slider against the frame.



3. Slide the angle-cut strap end over and back through the plastic slider, doubling the strap back on itself to eliminate the possibility of slippage.

ALICE COMPRESSION STRAP INSTRUCTIONS



4. Snug the angle-cut end tightly.
Repeat steps 1-4 on the opposite side of the frame for the remaining female SRB strap.



5. With both female SRB straps unfastened, route the compression strap through the snap fastener webbing loops on the outside pockets of the ALICE pack.



6. Fasten the compression strap male SRBs to the female SRBs.