

Instructions applicable to all sizes

Rectangular Clothesline Cover & Assembly Kit



www.clevacover.com.au



PATENT 2005200760 PO BOX 977, OXENFORD, QLD 4210

www.clevacover.com.au

IMPORTANT INFORMATION

Read through all information supplied prior to use.

- Recommended for permanently fixed clotheslines.
- Ensure removable clothesline in is properly secured and fixed in position prior to use of CLEVACOVER.
- Do not leave cover on clothesline if winds are greater than 20km / 11 knots (Beaufort scale No. 3)
- Cover may void your clothesline warranty.
- Not recommended as permanent fixture as strong winds may damage clothesline and cover.
- UV stabilised and water resistant.

PARTS INCLUDED 2200mm COVER

- 2 x Brackets
- 2 x Wing nuts for brackets
- 2 x Webbing straps
- 2 x 90 degree support bars
- 1 x Straight support bar
- 1 x Polyethylene fabric cover UV treated and water proof
- 1 x Warranty / Installation instructions

PARTS INCLUDED 3000mm & 3300mm COVER

- 2 x Brackets
- 2 x Wing nuts for brackets
- 2 x Webbing straps
- 2 x 90 degree support bars
- 3 x Straight support bar (two different sizes)
- 1 x Polyethylene fabric cover UV treated and water proof
- 1 x Warranty / Installation instructions



Photos are on the website. If you would like to place a review or tell a friend, please go to my website www.clevacover.com.au. Thank you for puchasing a **CLEVACOVER clothesline cover**. Please visit the website for the other great products.

CLEVACOVER WARRANTY

This CLEVACOVER is warranted for a period of **One Year** from date of purchase. The manufacturer agrees during the warranty period to repair any manufacturing defects in the product or, at its option, replace the product with another product or an equivalent product without cost to the owner for material or labour.

This warranty is subject to the original proof of purchase and the products being used in accordance with the instruction manual. This warranty does not cover defect due to modification, accident, damage caused by vandalism, rusting, acts of nature or any other event beyond the control of the manufacturer. Nor does this warranty cover scratching, scuffing, natural break down of materials that occur inevitably with extended use including Ultra Violet light damage or other cosmetic damage that may result from normal wear and tear.

In addition, defects resulting from intentional damage, negligence or unreasonable use will void this warranty. If the product is defective within the terms of this warranty, CLEVACOVER will repair or replace defective parts at no cost to the purchaser. Please note the shipping charges to and from the original place of purchase are not covered under warranty and are the responsibility of the purchaser. CLEVACOVER reserves the right to make substitutions to warranty claims if parts are unavailable or obsolete.

This warranty and CLEVACOVER including persons related to CLEVACOVER and the patent do not cover any incidental or other expenses including but not restricted to property damage, personal injury, death and any other incident that may occur while using or in the vicinity of any CLEVACOVER product.



OWNERS MANUAL AND INSTRUCTION BOOK

- Place bracket with wing nuts in the middle of side bars of clothesline. Tighten till firm. Brackets have a 50mm spigot which will face straight up when attached to the centre of clothesline side bar.
- Place 90 degree angle support bars on spigot of bracket with straight adjustable support bar in centre of your clothesline going from one side to the other side. Make sure the middle adjustable support bar is reasonable central in other support bars.
- 2A. For the 3000mm and 3300mm rectangular cover and kit. Slide the 2 smaller diameter straight poles inside the 90 degree angled poles. Slide the larger diameter straight pole over the 2 smaller diameter straight poles. Make sure that all poles are centrally located inside each other as this will make a strong and secure frame for the cover to go over.
- 3. Place cover over support bars with velcro edge to front of clothesline.
- 4. Put velcro edge of cover around the front bar of clothesline and press.
- 5. Velcro together so front bar of clothesline is in the middle of velcro loop.
- 6. Place straps through appropriate hole for clothesline size so black plastic ladder lock is on underside of cover.
- 7. Put strap between clothesline wall bracket at back of clothesline and side bar of clothesline. Bring strap back to ladder lock and thread from back of lock through middle bar, then turn strap back and loop through front bar where thumb and finger grip is.
- 8. Pull to tighten should be firm over support bars and clothesline.

FILL OUT INFORMATION BELOW FOR YOUR OWN RECORDS

Customer Name:	
Date of Purchase:	Invoice No
Item Code (See Packaging):	
	Clevacov

www.clevacover.com.au