

Assembly Instructions For The Classic Double Rocker

Tools Needed:

Power Screwdriver
#2 Square Drive Bit

Parts List:

Seat Assembly (1)
Back Assembly 2x2 Posts (2)
Back Assembly Arched Top Rail (1)
Back Assembly Back Rest Panel (1)
Arm & Leg Assemblies (2)
Rockers (2)

Hardware:

1/4" x 2-3/4" Bolts (4)
1/4" x 2" Bolts (10)
3" Screws (12)
Allen Wrench (1)

- Step 1** Place the seat assembly on edge on the floor with the front slat facing down. Place the arm assemblies on the proper sides (with the curved part of the arm on the outside) and align the holes in the legs with the holes on the side of the seat assembly. Insert a 2-3/4" bolt in each hole, turn in with the Allen wrench and semi-tighten only. **(Do not fully tighten any bolts until all bolts are in the proper holes).**
- Step 2** Take the 2x2 posts and find the 2 small predrilled holes in the sides of the posts, 1 is above & 1 is below the large predrilled hole with a metal insert. Align these holes with the predrilled holes in the ends of the backrest panel. There is 1 hole in the horizontal top rail & 1 hole in the bottom rail of the backrest. Attach with two 3" screws per side. Before tightening these screws place the arched top rail between the posts above the backrest panel & align with the two predrilled holes in the top of the posts. Attach the top rail with two 3" screws per side in the predrilled holes.
- Step 3** Lay the assembled back assembly down between the arms. Align the holes on the back of the arm with the holes in the side of the back assembly and fasten with two 2" bolts. Now take four 3" screws and fasten the bottom of the back assembly to the back of the seat assembly in the predrilled holes. There are no holes in the seat assembly as screws are self drilling. (You might have to loosen the arm and leg assembly slightly so the back fits in between the arms).
- Step 4** Now attach the rockers to the leg assemblies by aligning the holes in the rockers with the threaded inserts in the legs. Place the rockers on the outside of the legs, insert four 2" bolts through each rocker & turn into the inserts in the legs. Make sure you have the longer end of the rocker at the back of the chair. Now fully tighten all bolts with the Allen wrench.

