

Assembly Instructions For The 33" Poly Bar or Dining Table

Tools Needed For Assembly:

7/16" Wrench
7/16" Socket
Power Screwdriver
#2 Square Drive Bit

Parts List:

Table Top (1)
Leg Column (1)
Table Feet (4)

Hardware:

1/4" Flange Nuts (8)
2" Polybuster Screws (4)

- Step 1** Unpack and identify all parts and pieces. Lay a piece of cardboard on your work table or floor to prevent scratching your table top.
- Step 2** Set the leg column upright with the predrilled holes toward the top. Attach the table feet to the leg column by inserting the bolts in the feet into the holes on the leg column and put on the 1/4" flange nuts. Tighten securely with the 7/16" wrench or socket. **Note: The bottom of the feet need to be turned up when attaching to the leg column.**
- Step 3** Put the table top upside down on the cardboard. Now take the leg column and insert the other end into the 6" square frame in the center of the table top. Make sure the leg column is seated squarely inside the frame. Fasten with the four 2" screws by turning them through the predrilled holes in the poly frame. **Do not overtighten the screws or they will strip!**
- Step 4** Set the table upright, pull up some chairs and enjoy!

